

# M.O.L.E.<sup>®</sup> AttachEz<sup>™</sup>

Your Thermocouple Attachment Solution

- 1 Insert the Thermocouple bead through the **Hole**. Place bead on the adhesive side of the **Location Mark**.
- 2 **Fold #1** to secure the Thermocouple in place. **Fold #2** to create the AttachEz<sup>™</sup> "Tab".
- 3 Rotate the AttachEz<sup>™</sup> over.
- 4 The AttachEz<sup>™</sup> is ready for use.
- 5 When not in use, **Fold #3** to protect the Thermocouple bead.

